

CHAPTER IV > CLEANING & MAINTENANCE > 1 AUTO-DRIP BREWER, DISPENSER, & GRINDER > FETCO AUTO-DRIP BREWER

GH. IV: GLEANING & MAINTENANGE FETCO AUTO-DRIP BREWER

Daily

Wipe the area above the brew basket to remove coffee residue.



Clean the Cascading Spray Dome (CSD) with a soft brush and detergent.



3 Wipe down the exterior of the machine with stainless steel polisher.

Notes:

Weekly



- 1 Perform the daily cleaning.
- Soak your brew baskets in a bath with hot water and 3T of urn cleaner for 10-15 minutes. Use enough water such that the baskets are completely submerged. Once they have finished soaking, scrub them with a green scrubby to remove any coffee oils, stains, or particles. Rinse them thoroughly with cold water to remove any traces of urn cleaner.

Semi-Annually

- 1 Check brew levels to make sure that you are getting the programmed yield.
- 2 Check the temperature (programmed to brew at 202 degrees).
- 3 Check fittings to make sure that there are no visible leaks.
- Check filter to make sure that you are within the expiration date.

Notes: